



2 ½" End Post  
36" - PB7864  
42" - PB7868



2 ½" 90°  
Corner Post  
36" - PB7865  
42" - PB7869




2 ½" Mid Post  
36" - PB7866  
42" - PB7870




2" Mid  
Stair Post  
PB5834



2 ½" Top Stair  
Post (left side face)  
36" - PB5821  
42" - PB5830



2 ½" Top Stair  
Post (right side face)  
36" - PB5822  
42" - PB5831



2 ½" Top Stair  
Post (stair face only)  
36" - PB5824  
42" - PB5833




2 ½" Top Stair Post  
(opposite side face)  
36" - PB5823  
42" - PB5832



2 ½" Bottom  
Stair Post  
(left side face)  
36" - PB5825  
42" - PB5837



2 ½" Bottom  
Stair Post  
(right side face)  
36" - PB5826  
42" - PB5838



2 ½" Bottom  
Stair Post  
(stair face only)  
PB5835



2 ½" Bottom  
Stair Post  
(opposite side face)  
36" - PB5827  
42" - PB5836



To determine stair post need: Looking from the bottom of the stairs up, the side in which the level rail connects to the post is the post hand required.